

LINGUA VOX

User Manual

Welcome to Lingua Vox

Thank you for choosing the Emverra Lingua Vox. These smart glasses were designed for those who move through the world without limits — travelers, professionals, students, and global citizens who refuse to let language stand in the way of real human connection. This manual will guide you through everything you need to get started.

What's in the Box

- Emverra Lingua Vox Smart Glasses
 - USB Charging Cable
 - Protective Carrying Case
 - Lens Cleaning Cloth
 - Quick Start Card
-

Product Overview

Frame Material: TR90 — lightweight, flexible, and built for all-day wear

Lens Material: PC (Polycarbonate)

Camera: 800W Pixel (\approx 8MP) — built-in photo and video capability

Connectivity: WiFi, Bluetooth, USB

Certifications: CE, FDA

Getting Started

Step 1 — Charge Your Glasses Before first use, fully charge your Lingua Vox using the included USB cable. A full charge is recommended before initial setup.

Step 2 — Download the App Download the Emverra companion app on your Android or iOS device. Open the app and create your account or log in.

Step 3 — Pair via Bluetooth Enable Bluetooth on your smartphone. Open the app and select "Connect New Device." Hold the power button on your Lingua Vox for 3 seconds until the indicator light blinks. Select Lingua Vox from the device list to complete pairing.

Step 4 — Connect to WiFi Inside the app, navigate to Settings and connect your Lingua Vox to your preferred WiFi network for fast file transfers and real-time AI translation performance.

Step 5 — Set Your Languages Inside the app, navigate to Translation Settings. Select your native language and your target translation language. Lingua Vox supports multiple language pairs — choose the ones that match your destination or conversation needs.

Core Features

Real-Time AI Translation Lingua Vox delivers instant AI-powered translation directly through your glasses. Hear a foreign language and receive the translation in your ear in real time — no phone in hand, no pause, no friction. Communicate naturally in any language, anywhere in the world.

ChatGPT AI Voice Assistant Activate your built-in AI assistant hands-free by voice. Ask questions, get instant answers, identify objects around you, and navigate conversations intelligently — all without ever reaching for your phone.

Gesture Control Control your Lingua Vox without touching it. Use simple hand gestures to activate translation, manage calls, control audio playback, and navigate core functions — keeping both hands completely free at all times.

Bluetooth Audio Pair your Lingua Vox with your smartphone for hands-free calling and music playback directly through the glasses frame. Discreet, premium audio built into an elegant wearable design.

Audio Recording Lingua Vox includes a built-in microphone for audio recording — perfect for capturing conversations, meetings, lectures, and important exchanges for later reference.

⚡ **WiFi File Transfer** Transfer your recordings and files wirelessly to your smartphone or computer in seconds. No cables required. Open the app, select your files, and transfer instantly over your connected WiFi network.

Built-In Camera Lingua Vox includes an 800W pixel (≈ 8 MP) camera for photo and video capture — document your travels, capture moments, and record experiences hands-free.

Gesture Control Guide

Gesture	Action
Single tap on frame	Activate translation
Double tap on frame	Start / Stop audio recording
Swipe forward on frame	Next track / Accept call
Swipe backward on frame	Previous track / End call
Hold on frame	Activate AI voice assistant

Note: Gesture sensitivity can be adjusted inside the Emverra app.

Translation Guide

Supported Use Cases

- Live face-to-face conversation translation
- Airport signage and announcements
- Restaurant menus and local ordering
- Conference and business networking
- Street navigation in foreign cities
- Classroom and academic settings

How to Use Real-Time Translation

1. Open the Emverra app and ensure Lingua Vox is connected
2. Navigate to Translation Mode and select your language pair
3. Single tap the frame to activate translation
4. Speak or listen naturally — Lingua Vox handles the rest in real time
5. Single tap again to pause translation when not needed

Tips for Best Translation Performance

- Ensure a stable WiFi or mobile data connection for optimal AI performance
 - Speak clearly at a natural pace for most accurate results
 - In noisy environments, position yourself closer to the speaker
 - Regularly update the app for the latest language model improvements
-

Caring for Your Lingua Vox

- Clean lenses with the included microfiber cloth only
 - Avoid submerging in water
 - Store in the included protective case when not in use
 - Keep away from extreme heat or direct prolonged sunlight
 - Do not use abrasive materials on the frame or lenses
-

Charging & Battery

- Use only the included USB cable for charging
 - Charge in a dry, ventilated area
 - Do not charge overnight for extended periods
 - Battery indicator is visible inside the companion app
-

Privacy & Responsible Use

The Emverra Lingua Vox is designed to break language barriers and empower genuine human connection — for travelers, professionals, students, and global citizens.

Please use responsibly and always follow local consent and recording laws in your region. Never use Lingua Vox to record individuals without their knowledge or consent where prohibited by law.

Emverra is committed to responsible technology. We trust our users to uphold the same standard.

Troubleshooting

Glasses won't turn on Ensure the device is fully charged. Hold the power button for 3 full seconds.

Bluetooth won't connect Turn Bluetooth off and on again on your phone. Restart Lingua Vox and attempt pairing again through the app.

Translation not working Ensure your smartphone has an active WiFi or mobile data connection. Check that Translation Mode is active inside the app. Restart the app and retry.

Translation response is delayed Check your internet connection strength. Move closer to your WiFi router or switch to a stronger mobile data signal for faster AI response times.

WiFi transfer not working Ensure both your phone and Lingua Vox are connected to the same WiFi network. Restart the app and retry.

Gesture control not responding Clean the touch-sensitive area on the frame with a dry cloth. Recalibrate gesture sensitivity inside the app settings.

Support

For assistance, reach out to the Emverra support team:

- Email: support@emverra.com
- Social: @emverra on TikTok, Instagram, Facebook
- Response Time: within 24 hours

We are committed to resolving every issue with care and urgency.

Legal & Compliance

- Certifications: CE, FDA
 - Always follow local laws regarding audio recording and translation use
 - Emverra is not liable for any miscommunication resulting from AI translation output
 - Translation accuracy may vary depending on language pair, connection quality, and environmental conditions
-

Emverra — Unseen Power Version 1.0