

# VISTA ONE

## User Manual

### Welcome to Vista One

Thank you for choosing the Emverra Vista One. These smart glasses were designed for those who live life in motion — adventurers, creators, and professionals who need to capture every moment without ever stopping to hold a phone. This manual will guide you through everything you need to get started.

---

### What's in the Box

- Emverra Vista One Smart Glasses
  - USB Charging Cable
  - Protective Carrying Case
  - Lens Cleaning Cloth
  - Quick Start Card
- 

### Product Overview

Frame Material: TR90 — lightweight, flexible, and built for all-day wear

Lens Material: PC (Polycarbonate)

Camera: 800W Pixel (≈8MP) — built for photo and video capture

Connectivity: WiFi, Bluetooth, USB

Certifications: CE, FDA

---

### Getting Started

Step 1 — Charge Your Glasses Before first use, fully charge your Vista One using the included USB cable. A full charge is recommended before initial setup.

Step 2 — Download the App Download the Emverra companion app on your Android or iOS device. Open the app and create your account or log in.

Step 3 — Pair via Bluetooth Enable Bluetooth on your smartphone. Open the app and select "Connect New Device." Hold the power button on your Vista One for 3 seconds until the indicator light blinks. Select Vista One from the device list to complete pairing.

Step 4 — Connect to WiFi Inside the app, navigate to Settings and connect your Vista One to your preferred WiFi network for fast file transfers.

---

### Core Features

Hands-Free Camera Vista One features an 800W pixel (≈8MP) built-in camera on the frame, designed for seamless hands-free photo and video capture. Simply wear your glasses and capture — no setup, no holding, no missing the moment.

**Gesture Control** Control your Vista One without touching it. Use simple hand gestures to take photos, start and stop video recording, and navigate basic functions — keeping both hands completely free at all times.

↶ **WiFi File Transfer** Transfer your photos and videos wirelessly to your smartphone or computer in seconds. No cables required. Open the app, select your files, and transfer instantly over your connected WiFi network.

**ChatGPT AI Assistant** Activate your built-in AI assistant hands-free by voice. Ask questions, get real-time information, identify objects, and interact intelligently — all without reaching for your phone.

**Bluetooth Audio Pair** your Vista One with your smartphone for hands-free calling and music playback directly through the glasses frame. Crystal clear audio built into a sleek, wearable design.

**Audio Recording** Vista One includes a built-in microphone for audio recording — perfect for capturing field notes, on-site documentation, and voice memos on the go.

---

---

## Gesture Control Guide

Gesture	Action
Single tap on frame	Take a photo
Double tap on frame	Start / Stop video recording
Swipe forward on frame	Next track / Accept call
Swipe backward on frame	Previous track / End call

*Note: Gesture sensitivity can be adjusted inside the Emverra app.*

---

---

## Caring for Your Vista One

- Clean lenses with the included microfiber cloth only
- Avoid submerging in water
- Store in the included protective case when not in use
- Keep away from extreme heat or direct prolonged sunlight
- Do not use abrasive materials on the frame or lenses

---

---

## Charging & Battery

- Use only the included USB cable for charging
- Charge in a dry, ventilated area
- Do not charge overnight for extended periods
- Battery indicator is visible inside the companion app

---

---

## Privacy & Responsible Use

The Emverra Vista One is designed for hands-free personal capture — outdoor sports, creative content, and professional field documentation.

Please use responsibly and always follow local consent and recording laws in your region. Never use Vista One to record individuals without their knowledge or consent where prohibited by law.

Emverra is committed to responsible technology. We trust our users to uphold the same standard.

---

## Troubleshooting

**Glasses won't turn on** Ensure the device is fully charged. Hold the power button for 3 full seconds.

**Bluetooth won't connect** Turn Bluetooth off and on again on your phone. Restart Vista One and attempt pairing again through the app.

**WiFi transfer not working** Ensure both your phone and Vista One are connected to the same WiFi network. Restart the app and retry.

**Gesture control not responding** Clean the touch-sensitive area on the frame with a dry cloth. Recalibrate gesture sensitivity inside the app settings.

**Camera quality appears low** Ensure the lens is clean and free of smudges. Adjust camera settings inside the companion app for optimal output.

---

## Support

For assistance, reach out to the Emverra support team:

- Email: [support@emverra.com](mailto:support@emverra.com)
- Social: @emverra on TikTok, Instagram, Facebook
- Response Time: within 24 hours

*We are committed to resolving every issue with care and urgency.*

---

## Legal & Compliance

- Certifications: CE, FDA
  - Always follow local laws regarding camera use and audio recording
  - Emverra is not liable for misuse of the Vista One camera or recording functions
- 

*Emverra — Unseen Power Version 1.0*